

DOCUMENTATION

American Audio VMS5



- | | |
|-------------------------------|---------------------------------|
| 1 Play | 22 Safe/Play Cue 3 (CM) |
| 2 Cue | Delete Cue 3 (Shift) |
| 3 Scratching/Pitch-Bending | Sample 3 (SM) |
| 4 Pitch-Down | 23 Search Backward |
| 5 Pitch-Up | 24 Adjust Cutoff |
| 6 Pitch-Fader | 25 Cutoff On/Off |
| 7 Sync On/Off | 26 Safe/Play Cue 4 (CM) |
| 8 Pitch-Reset | Delete Cue 4 (Shift) |
| 9 Switch to Cue-Mode (CM) | Sample 4 (SM) |
| 10 Switch to Sample-Mode (SM) | 27 Search Forward |
| 11 Brake FX | 28 Channel Gain |
| 12 Adjust Flanger | 29 High EQ |
| 13 Flanger On/Off | 30 Mid EQ |
| 14 Safe/Play Cue 1 | 31 Low EQ |
| Delete Cue 1 (Shift) | 32 Master Volume |
| Sample 1 (SM) | 33 Monitor Volume |
| 15 Shift | 34 Navigate through Songlist |
| 16 Adjust Cutoff + Resonance | Load Song on Left Deck (Left) |
| 17 Cutoff + Resonance On/Off | Load Song on Right Deck (Right) |
| 18 Safe/Play Cue 2 | Transfer Focus Forward (Up) |
| Delete Cue 2 (Shift) | Transfer Focus Backward (Down) |
| Sample 2 (SM) | 35 Monitor Channel On/Off |
| 19 Scratch Mode On/Off | 36 Channel Fader |
| 20 Decrease Loop Length (TAP) | 37 Cross Fader |
| Increase Loop Length (Turn) | |
| 21 Loop On/Off | |