

DOCUMENTATION

DenonDJ MC4000



- 1 Cue
- 2 Play
- 3 Scratching/Pitch-Bending
- 4 Pitch Fading
- 5 Next Pitch Range (Shift)
- 6 Pitch-Bend-Down
Search Backward (Shift)
- 7 Pitch-Bend-Up
Search Forward (Shift)
- 8 Shift
- 9 Sync BPM
- 10 Cue 1
Delete Cue 1 (Shift1)
- 11 Cue 2
Delete Cue 2 (Shift1)
- 12 Cue 3
Delete Cue 3 (Shift1)
- 13 Cue 4
Delete Cue 4 (Shift1)
- 14 Vinyl Mode On/Off
- 15 Loop On/Off
Loop 4 Range (Shift)
- 16 Decrease Loop
Loop In (Shift)
- 17 Increase Loop
Loop Out (Shift)
- 18 Flanger On/Off
Brake FX (Shift)

- 19 Cutoff On/Off
Beatgrid FX (Shift)
- 20 Resonance On/Off
Spin Forward FX (Shift)
- 21 Flanger Gain
- 22 Cutoff Gain
- 23 Resonance Gain
- 24 Cutoff + Resonance Gain
- 25 Crossfader
- 26 Channel Fader
- 27 Sample Volume
- 28 Monitor On/Off
- 29 Cutoff + Resonance On + Gain
- 30 Low EQ
- 31 Mid EQ
- 32 High EQ
- 33 Channel Gain
- 34 Load Song to Left Deck
- 35 Navigate in List/Jump To Next View
- 36 Load Song to Right Deck
- 37 Jump To Previous View
- 38 Load Waitlist
- 39 Sample 1
- 40 Sample 2
- 41 Sample 3
- 42 Sample 4
- 43 Monitor Gain
- 44 Master Gain