


DOCUMENTATION

Numark 4Trak



- 1 CUE-Play
- 2 Play
- 3 Scratching/Pitch-Bending
- 4 Pitch Range
- 5 Pitch Fading
- 6 Pitch down
- 7 Pitch up
- 8 Shift (Hold to Delete Cues)
- 9 Cue 1
- 10 Cue 2
- 11 Cue 3
- 12 Cue 4
- 13 Cue 5
- 14 Toggle between Scratch- and Pitch-Bending-Mode
- 15 Loop In
- 16 Loop Out
- 2 Loop (Shift)
- 17 Activate/Deactivate Loop
- 4 Loop (Shift)

- 18 16 Loop (Shift)
- 19 32 Loop (Shift)
- 20 Downscale Loop
- 21 Upscale Loop Loop
- 22 Search
- 23 Crossfader
- 24 Channel Fader
- 25 Monitor Channel
- 26 Low EQ
- 27 Mid EQ
- 28 High EQ
- 29 Channel Gain
- 30 Effect 1
- 31 Effect 2
- 32 Both Volume
- 33 Load on Left Deck
- 34 Navigate/Preview
- 35 Load on Right Deck

- 36 Master Gain
- 37 Open Group
- 38 Show Song-View
- 39 Record On/Off
- 40 AGC On/Off
- 41 Switch to Next View
- 42 Auto DJ On/Off
- 43 Fading-Widget Next
- 44 Talk Over On/Off
- 45 Sampler Volume
- 46 Mixer Volume
- 47 Fading Duration
- 48 If Active: Cutoff + Resonance Gain
- If Inactive: Flanger Gain
- 49 Flanger Gain
- 50 Cutoff Gain
- 51 Resonance Gain
- 52 Cutoff Gain