



DOCUMENTATION

Numark Partymix



- 1 - Cue Mode 1 (CM1)
- 2 - Loop Roll
- 3 - Sample Mode
- 4 - Play / Pause
- 5 - Cue
- 6 - Performance Pads
- 7 - Sync
- 8 - Pitchfader
- 9 - Jogwheel
- 10 - Cue
- 11 - Crossfader
- 12 - Linefader
- 13 - Gain
- 14 - Browser library scroll.
Push to select file.
- 15 - Treble
- 16 - Bass